




No.	Part Name(Chinese)	Part Name(English)	Code	Qty	No.	Part Name(Chinese)	Part Name(English)	Code	Qty
1	止动杆	Stop Shaft	10306005074	1	50	内六角带垫螺钉M6×20	Screw M6×20	30207087	10
2	铁头	Iron head	10306006100	1	51	轴承6201	Bearing 6201	30103210	1
3	内六角带垫螺钉M10×35	Screw M10×35	30207100	6	52	小齿轮	Small Gaer	10302004192	1
5	销锁套	Pin Lock Sleeve	10306002158	1	53	沉头螺钉M5×12	Screw M5×12	30201057	6
6	圆柱销4×18	Cylindeical Pin 4×18	30701079	1	54	轴承压盖24×2	Bearing Cover 24×2	10401002064	1
7	锁套弹簧	Spring	10303001162	1	55	轴承6001	Bearing 6001	30103213	1
8	平垫片18×12.2×1.2	Flat Washer 18×12.2×1.2	30403185	2	56	轴承压盖32×2	Bearing Cover 32×2	10401002065	1
9	O形圈60×2	O Ring 60×2	10102003232	2	57	平垫片39.9×31.5×2	Flat Washer 39.9×31.5×2	30403187	1
10	导向套缓冲垫	Guide Sleeve Cushion	10102004125	1	58	轴承6203	Bearing 6203	30103211	1
11	O形圈23.6×5	O Ring 23.6×5	10102003229	1	59	转子	Armature	10502001355	1
12	导向座	Guide Seat	10306006101	1	60	自攻螺钉ST5×75	Screw ST5×75	30202081	2
13	开口套	Split Sleeve	10306002157	1	61	挡风圈	Air Deflector	10101005205	1
14	开口套橡胶圈	Rubber Ring for Split Sleeve	10102004126	1	62	定子	Stator	10501001330	1
15	平垫片68.5×57.5×2	Flat Washer 68.5×57.5×2	30403186	1	63	轴承6201	Bearing 6201	30103214	1
16	小缓冲垫圈	Buffer Washer	10101011285	1	64	机壳	Housing	10101001448	1
17	内六角带垫螺钉M8×40	Screw M8×40	30207099	4	65	刷架	Brush Holder	10606001200	2
20	前筒	Front Barrel	10208004061	1	66	盘簧	Spring	10303002025	2
21	气缸	Cylinder	10306004023	1	67	碳刷	Carbon Brush	10605001200	2
22	活塞Y型密封圈	Sealing Ring	10102003228	1	68	自攻螺钉ST4×10	Screw ST4×10	30202013	10
23	铝活塞	Aluminum Piston	10306003031	1	69	刷架盖	Brush Cover	10101008168	2
24	活塞销12×44	Piston Pin 12×44	30701121	1	70	油箱盖板	Cover Plate for Oil Box	10401004065	1
25	半圆键4×6.5×16	Woodruff Key 4×6.5×16	30601010	2	71	O形圈20×2	O Ring 20×2	10102003230	1
26	偏心轴	Crank Shaft	10301003024	1	72	油眼	Oilhole	10401008056	1
27	滚针轴承NK18/20	Bearing NK18/20	30101034	1	73	自攻螺钉ST5×18	Screw ST5×18	30202129	4
28	连杆	Connecting Rod	10306005073	1	74	手柄	Handle	10101004534	1
29	连杆压板	Pressing Plate for Connecting Rod	10401002063	1	75	开关	Switch	10601001286	1
30	弹性挡圈8	Circlip 8	30401015	2	76	电缆压板	Cord Anchor	10101011288	1
31	内六角螺钉M8×25	Screw M8×25	30207102	1	77	圆形塑料接线扣4.2	Plastic Wiring Buckle 4.2	30801045	2
32	快拆盖	Quick-released Cover	10101008169	1	78	手柄盖	Handle Cover	10101004535	1
33	O形圈37×2	O Ring 37×2	10102003231	1	79	塑料接线帽4	Plastic Wiring Cap 4	30802007	1
34	内六角带垫螺钉M6×25	Screw M6×25	30207080	10	80	电缆护套	Cord Sleeve	10102001051	1
37	上盖	Upper Cover	10204004221	1	81	电源线2×1	Cord 2×1	10602006010	1
38	轴承6302	Bearing 6302	30103215	1	82	辅助手柄螺栓M8×110	Screw M8×110	30206068	1
39	轴用弹性挡圈22	Circlip for Shaft 22	30301010	1	83	弓形抱箍	Bow Hoop	10401008057	1
40	大齿轮	Big Gear	10302004191	1	84	夹紧块	Clamping Block	10101011286	2
41	衬套	Bush	10306002159	1	85	锁紧旋钮	Locking Knob	10101007267	1
42	内六角带垫螺钉M5×16	Screw M5×16	30207016	4	86	六角螺母M8	Nut M8	30501115	1
43	轴承压盖40×2	Bearing Cover 40×2	10401002066	1	87	旋钮盖	Knob Cover	10101008170	1
44	轴承6205	Bearing 6205	30103212	1	88	绝缘套	Insulating Sleeve	10102004129	2
45	葫芦圈	Gourd Ring	10102004127	1	89	圆柱销3×30	Cylindeical Pin 3×30	30701094	2
46	减速箱	Gear Box	10205004043	1	90	绝缘帽	Insulating Cap	10102004128	2
47	O形圈100×2.5	O Ring 100×2.5	10102003234	1	91	辅助手柄	Auxiliary Handle	21201001084	1
48	油绳	Oil Rope	21201010103	1	92	油管	Oil Pipe	40101037	1
49	油箱	Oil Box	10101011284	1	93	油眼扳手	Oilhole Wrench	21201002068	1
Version No.		D			Enable Time		2022.9		

