




No.	Part Name(Chinese)	Part Name(English)	Code	Qty	No.	Part Name(Chinese)	Part Name(English)	Code	Qty
1	上压板	Out Flange	10305001082	1	51	头壳组件由12、17、18、19、20、21零件组件	Gear Box Complete (contain12. 17. 18. 19. 20. 21)	10701001011	1
2	砂轮片100	Grinding Wheel 100	21201006041	1	52	侧手柄M8	Side handle M8	21201001041	1
3	下压板	Inner Flange	10305001084	1					
4	砂轮罩100	Wheel Guard 100	10401001006	1					
7	输出轴	Output Spindle	10301001055	1					
8	半圆键3×3.7×10	Woodruff Key 3×3.7×10	30601004	1					
9	带平弹垫螺钉M4×14	Screw M4×14	30201011	4					
12	前盖	Front Cover	10203004015	1					
13	轴承6201	Bearing 6201	30104036	1					
14	孔用弹性挡圈32	Circlip for Hole 32	30302014	1					
15	大锥齿轮	Big Gear	10302009015	1					
16	轴用弹性挡圈12	Circlip for Shaft 12	30301023	1					
17	含油轴承8×12×8	Bearing 8×12×8	30102022	1					
18	头壳	Gear Box	10201004257	1					
19	自锁弹簧	Self-lock Spring	10303001044	1					
20	自锁销	Self-lock Pin	10306001008	1					
21	自锁帽	Self-lock Cap	10101007071	1					
22	自攻螺钉ST4×22	Screw ST4×22	30202032	4					
23	六角法兰面螺母M6	Nut M6	30501041	1					
24	小锥齿轮	Small Gear	10302009016	1					
25	轴承629	Bearing 629	30104057	1					
26	中间盖	Middle Cover	10401002018	1					
27	转子	Armature	10502001106	1					
28	轴承607	Bearing 607	30104018	1					
29	轴承衬套	Bearing Sleeve	10102002019	1					
30	自攻螺钉ST4×65	Screw ST4×65	30202050	2					
31	定子	Stator	10501001088	1					
32	拉簧	Spring	10607001022	2					
33	机壳	Housing	10101001119	1					
34	铭牌	Nameplate	20302007129	1					
35	刷握	Brush Holder	10606001168	2					
36	碳刷	Carbon Brush	10605001048	4					
37	刷握盖	Brush Holder Cover	10606001169	2					
39	Y型插片3.2	Y-shaped Insert 3.2	30801022	2					
40	开关	Switch	10601001100	1					
41	电感	Inductance	10604001034	1					
42	开关座	Switch Set	10101011034	1					
43	电缆压板	Cord Anchor	10101011007	1					
44	自攻螺钉ST4×14	Screw ST4×14	30202019	3					
45	后罩	Rear Cover	10101003030	1					
46	电容	Capacitor	10603001005	1					
47	电缆护套	Cord Sleeve	10102001045	1					
49	电源线2×0.75	Cord 2×0.75	10602006130	1					
50	带销扳手20	Wrench 20	21201002043	1					
Version No.		D			Enable Time		2022.9		